

As quick as the fire brigade

No matter whether there is a fire, danger to life or to the environment – the fire brigade is always there ! It has to be quick and reliable and so does the equipment.

The brake pressure of fire engines must always be in perfect working order, so that they are always ready to go. The piston compressors from Dürr Technik are ideal for this. The powerful compressors of the Marathon series easily generate oilfree compressed air up to 12 bars. Their compact design enables them to fit even into tricky places combined with their extremely long lifetime makes them stand out. The excellent technology, the accurate machining with the smallest tolerances and the precise assembly are proof of the high quality of the products. Depending on the model, they deliver from 80 to 300 l/min at free airflow.

The oilfree technology has significant advantages. Intensive maintenance as with oil lubricated compressors is no longer necessary, this saves time and money. There is no oil vapour to pollute the environment, either. The filters can be changed quickly and easily without any tools.

The oilfree piston compressors of the marathon range are available in four different standard sizes, 230 V 1 phase AC and 400 V 3-phase motor, with protection class IP 54. DÜRR TECHNIK offer complete „plug & play“ stations or tailor-made customer solutions.



caption:

Quick, reliable and safe. The oil free compressors of the marathon range ensure oilfree compressed air at the fire station. The advance technology delivers extremely long life and being oil free the products are virtually maintenance free.

picture: Dürr Technik